

INSTALLATION GUIDE

Patent No: 2017100415

STEPS:

1. Plan layout before starting.
2. Trim bottom panel to floor with groove to the top, ensuring first line is level.
 - Use a suitable construction adhesive to secure the bottom of this panel
3. Put rubber spacers in groove two per panel spaced to be near both ends of the panel to go above.
4. End joints must be staggered unless on a stud or joist.
5. Ensure all cuts are fully coated with Endurapanel[®] coloured primer.
 - Apply Endurapanel[®] coloured primer liberally to cut edge, wiping off excess with a rag.
6. Using 8G 25mm countersunk screws, affix the Connectaply to the stud or joist as per the diagram
7. Fixings at 600 centres.

